



Smartphone-Controlled Electronic Lock



ATENTION:


- Keep mechanical keys in a safe place different from the lock installation place so that ir emergency/breakdown cases the door can be opened mechanically.
- 2. Pay attention to the battery level to be able of replacing the batteries on time.
- 3. Carefully read the manual before any installation and keep it for future use.








Dimensions



Types of Mortice / Mechanical Locks










Installation

1.1 Installation Diagram









Technical Specifications

Models	TW21N FP	
Material	SS304	
Handle sizes	148*27	
	Bluetooth	
Opening Methods	Mechanical key	
	Fingerprint	
	Silver	
Colour	Black	
	Metal/wooden door	
Door types	Sliding doors	
Voltage/battery	6V/4x AAA	
Door width	30-50mm	
Data storage	Unlimited: management by APP	
Operating temperature	-25°C +60°C	
Operating humidity	20% ~ 90%	
Voltage alarm	Less than 4.5V	
Rejection percentage of digital fingerprint	<0.01%	
Acceptance percentage of false digital fingerprint	<0.0003%	







Lock initialization:

Open the battery compartment at the back panel and press the RESET button for 5 seconds. (The RESET button is marked in an orange circle on the image).



Smartphone Application

TTLOCK application download

Download the app from the Play Store/App Store from your smartphone - Android or iOS (the following QR code can be used to be directed to the application).














Create an application account




- 1. Press Registration to create an account.
- 2. Select the registration mode by phone.
- 3. Select the country of your telecommunication operator and after filling in the data click on **Get code**. You are going to receive a SMS with the validation code.
- 4. After entering the received code, click on Registration.







First Login



Click on the profile icon created, at the upper left corner, for the following options:

- 1. Profile settings Profile picture, modification of access credentials or name, etc.
- 2. Add lock Add a new access control.
- 3. Gateway Add and manage TW-GATE devices.
- 4. Settings Application settings and transfer of equipment to other accounts.

Add device

Make sure the device is connected to the power supply before starting the set up; it is recommended to perform a RESET.









- 1 Press Add device or "+".
- 2 Select Lock
- 3 Activate device (press fingerprint on the fingerprint sensor) or continuously press the RESET button until there is a sound signal followed by two beeps. Press Next.
- 4 Next, the application is going to search for the access control by Bluetooth:
 - 1. On the mobile app is going to appear the name and symbol + (if there is no symbol + the RESET must be carried out again).
 - 2. Press the symbol + to finish the initial synchronization.
- 5 Assign a name to the access control added and press OK.








Device management

Main device menu



Opening by the application/keypad

Press the symbol



Note: This function is only available by being next to the lock (locally) by Bluetooth.







Add fingerprints

Select Fingerprints




• In order to record a fingerprint, you need to be close to the lock and wait for the synchronization and then, follow the application instructions.

Assigned fingerprint management



• Fingerprint – Management of fingerprints created until that moment. Fingerprints can be deleted if the entire process is carried out locally by using Bluetooth or by using the TW-GATE device.










Opening records



This entire process needs to be carried out locally, by Bluetooth or WIFI connection to the TW-GATE.

Device settings



This entire process needs to be carried out locally by Bluetooth or WIFI connection to the TW-GATE.









Add Gateway (Optional)

Gateway Light Meaning



Pairing the gateway to the device



- After successfully adding the gateway, the application will automatically search for devices within the gateway's range.
 - Attention: If time is exceeded, disconnect the gateway from the power supply and connect it back again.







		User Manual	
Front plate	Back plate	Instruction manual	Mortice lock
1	1	1	1
0			
Mechanic cylinder	Mechanical keys	Fixing screw	Fixing screw for armature plate
1	2	4	4
	*		
Threaded connector nut (different sizes)	TW-GATE (optional)		
8	4		







Warranty	1	
	15	
Client Name:		
Client Phone number:		
Purchase Date:		
Product:	·	_
Model:		
Note: 1) Please keep this manual in order fo	r you to use it when the warranty service is	needed.
2) Warranty has a two-year validity fro	om the purchase date.	
purchase date. The warranty does not have a covelectric installation not checked by	nufacturing defects by the warranty, with a erage for breakdowns caused by a misuse riplo W., by natural disasters such as: so wear components depending on use.	of the system, by a poor
	Seal and Signat	ture from Dealer

