



TRIPLO W
Criamos Segurança

TW400K

Installation Guide
User Manual


Fingerprint, Touch Keyboard, Card Reader with Bluetooth/Wi-Fi connection



Bluetooth
4.1







* ap en as co
mgateway




Leia o manual com atenção antes da instalação e guarde-o para uso futuro.

Dimensions

1




NOT INCLUDED
(optional)
Gateway for Wi-Fi




TW - GATE

Technical Specifications




MATERIAL	Aluminum
COLOR	Silver / Black
DIMENSIONS (mm)	125 x 79 x 18.5 mm
WEIGHT (KG)	1.1 kg
DEGREE OF PROTECTION	IP66
TYPES OF OPENING	Fingerprint, Bluetooth4.1, APP, Code, Card Proximity
COMPATIBLE SOFTWARE	TTLock, TTHotel, TTRenting
VOLTAGE	12V DC
CONSUMPTION (OPERATION)	1 A
CONSUMPTION (STANDBY)	15 mA
DATA CAPACITY	100 Cards
WORKING TEMPERATURE (°C)	- 20° ~ +65°
WORKING HUMIDITY (%)	30%~95%
READING DISTANCE	< 55mm
RECOGNITION TIME (/s)	1.5 s
GATEWAY	Not included, required for Wi-Fi




in
the
to the



air
the




Power Supply





Electrical Scheme


Source of Food
the K80



Source of Food
Common



Restart



To reset the product, you must unscrew the back.

With the equipment connected, press the golden button shown in the image to the side for a few seconds and enter the code 000# on the keypad.

The process will be successful if at the end the device says "Deleted administrator successful"