

TW500K

Installation Guide User Manual Facial recognition, Fingerprint, Touch keyboard, Card reader with Bluetooth/Wi-Fi connection

















Dimensions 1




Technical Specifications

| MATERIAL | Aluminum |
|--------------------------|---------------------------------------------------------------------------|
| COLOR | Silver / Black |
| DIMENSIONS (mm) | 145 x 80 x 20mm |
| WEIGHT (KG) | 1.1 kg |
| TYPES OF OPENING | Facial Recognition, Fingerprint, Bluetooth 4.1, APP, Code, Proximity Card |
| COMPATIBLE SOFTWARE | TTLock, TTHotel, TTRenting |
| VOLTAGE | 12V DC |
| CONSUMPTION (OPERATION) | 1 A |
| CONSUMPTION (STANDBY) | 15 mA |
| WORKING TEMPERATURE (°C) | - 20° ~ +65° |
| WORKING HUMIDITY (%) | 30%~95% |
| READING DISTANCE | < 55mm |
| RECOGNITION TIME (/s) | 1.5 s |
| CAPACITY | Facial recognition: 100; Carttheo: 1000; Printthethe digital: 100 |
| GATEWAY | Not included, required for Wi-Fi |

Installation 2



Electrical Scheme





Reset

To reset to factory settings you must unscrew the back.

With the equipment connected, press the golden button shown in the image to the side for a few seconds and enter the code 000# on the keypad.

The process will be successful if at the end the device says "Deleted administrator successful"

Restart