



TRIPLO W  
Criamos Segurança!

# TW300K

Installation Guide User  
Manual

**Touch Keyboard | Card Reader  
with Bluetooth / Wi-Fi connection**



**TTLOCK APP**

<https://triplow.pt/TTLOCK>



App Store




Google Play



Bluetooth  
4.1




\* only with  
mgateway




**ATTENTION:**

Leia o manual com atenção antes da instalação e guarde-o para uso futuro.


[www.triplow.pt](http://www.triplow.pt)






MATERIAL	Aluminum
COLOR	Silver / Black
DIMENSIONS (mm)	125 x 79 x 18.5 mm
WEIGHT (KG)	1.1 kg
DEGREE OF PROTECTION	IP66
TYPES OF OPENING	Bluetooth 4.1, APP, Code, Proximity Card
COMPATIBLE SOFTWARE	TTLock, TTHotel, TTRenting
VOLTAGE	12V DC
CONSUMPTION (OPERATION)	1 A
CONSUMPTION (STANDBY)	15 mA
DATA CAPACITY	100 Cards
WORKING TEMPERATURE (°C)	- 20° ~ +65°
WORKING HUMIDITY (%)	30%~95%
READING DISTANCE	< 55mm
RECOGNITION TIME (/s)	1.5 s
GATEWAY	Not included, required for Wi-Fi




in  
the  
to the



r  
the




Power Supply





## Electrical Scheme


# Source of Food the K8



Source of  
Food  
Common



# Restart



To reset the product, you must unscrew the back.

With the equipment <sup>connected,</sup> press the golden button shown in the image to the side for a few seconds and enter the code 000# on the keypad.

The process will be successful if at the end the device says "Deleted administrator successful"

